


SN1AT71 Restore Factory Settings SOP

Android version 4.2.2


1. Select the All Apps icon. See red arrow head →




2. Select the Settings icon.



3. Open Backup & reset.



4. Select Factory data reset




SN1AT71 Restore Factory Settings SOP

Android version 4.2.2


Note: This will erase from the device

User's Google Account / System, application data and settings / Downloaded applications.


5. Tick erase SD card, in case you want to clear music, pictures and other user data.




6. Select Reset tablet button.



7. Select Erase everything button. After that the tablet will reboot.



8. After the process as shown on the picture below is done, the tablet will switch off. Then the factory reset is complete.



SN1AT71 Restore Factory Settings SOP

Android version 4.2.2

9. The first boot process after reset may take up to 2 minutes.



10. The Factory Reset is done.

